



livo⁺

HIGH-WALL DUCTLESS AIR CONDITIONING & HEATING SYSTEM

Models:

LIVS09HP115V1B	LIVS18HP230V1B
LIVS12HP115V1B	LIVS24HP230V1B
LIVS09HP230V1B	LIVS30HP230V1B
LIVS12HP230V1B	LIVS36HP230V1B
	LIVS36HP230V1C

NOTE: Please read the complete owner's manual carefully before operation.



INDOOR UNIT FRONT PANEL DISPLAY: Look here for LED display of system status, setpoint, indoor and outdoor temperatures and malfunction codes.



Press to power the unit on or off.



Press to select fan speed (Auto, Low, Medium, High or Turbo). Auto is default.



Press to select and adjust each mode.

☀️ : HEAT 🔥 : DRY ⚙️ : AUTO
❄️ : COOL 🌀 : FAN ONLY



Press to raise settings including temperature and time.



Press to control vertical angle of louvers and to redirect airflow.



Press to boost cooling or heating airflow. Quickest way to reach preset temperature.



Press to lower settings including temperature and time.



Press to select temperature display: indoor, outdoor or desired room temperature (Adjust desired temperature with "▲" and "▼" buttons.)



Press to select SLEEP mode, offering custom comfort control while sleeping. See Owner's Manual for more details.



Press to activate; allows unit to sense temperature at the remote controller.



Press to display time of day.



Press to turn on lights on the unit's Front Panel Display. Press again to turn off.



Press to start or stop the timer. (Adjust with "▲" and "▼" buttons.) See Owner's Manual for more details.



livo+

HIGH-WALL DUCTLESS AIR CONDITIONING & HEATING SYSTEM



















Models:

LIVS09HP115V1B	LIVS18HP230V1B
LIVS12HP115V1B	LIVS24HP230V1B
LIVS09HP230V1B	LIVS30HP230V1B
LIVS12HP230V1B	LIVS36HP230V1B
	LIVS36HP230V1C

NOTE: Please read the complete owner's manual carefully before operation.



INDOOR UNIT FRONT PANEL DISPLAY: Look here for LED display of system status, setpoint, indoor and outdoor temperatures and malfunction codes.

-  Press to power the unit on or off.
-  Press to select fan speed (Auto, Low, Medium, High or Turbo). Auto is default.
-  Press to select and adjust each mode.
 -  : HEAT
 -  : DRY
 -  : AUTO
 -  : COOL
 -  : FAN ONLY
-  Press to raise settings including temperature and time.
-  Press to control vertical angle of louvers and to redirect airflow.
-  Press to boost cooling or heating airflow. Quickest way to reach preset temperature.
-  Press to lower settings including temperature and time.
-  Press to select temperature display: indoor, outdoor or desired room temperature (Adjust desired temperature with "▲" and "▼" buttons.)
-  Press to select SLEEP mode, offering custom comfort control while sleeping. See Owner's Manual for more details.
-  Press to activate; allows unit to sense temperature at the remote controller.
-  Press to display time of day.
-  Press to turn on lights on the unit's Front Panel Display. Press again to turn off.
-  Press to start or stop the timer. (Adjust with "▲" and "▼" buttons.) See Owner's Manual for more details.